


Scale-Link™

USB Version

The industry standard take-off tool for entering linear measurements from your blueprints, maps, or plans into any Windows program. Just roll the scaler wheel along your print, then click to instantly transfer the measurement into your program. Scale-Link includes the scaler wheel, connecting cable and transfer software.




Select units of readout
(inches, feet, yards, meters, etc.)

Change user defined
scales, adder, etc.

Zero the count
and length

Click here to
transfer length from
PlanWheel XLU into
software program

Transfer count from
PlanWheel XLU into
software program



Select scale factors
(architectural,
engineering,
map, metric)

The Ready Connect™ window indicates readout from the PlanWheel XLU™.

Scale-Link Includes:

- PlanWheel XLU™ Scaler
- Ready Connect™ Software
- USB Cable
- Protective Case
- One Year Warranty
- User Manual

Scale-Link is specially suited for:

- All Windows construction estimating software
- Excel®, Quatro Pro®, Lotus 1-2-3® and other spreadsheets
- Access®, dBase®, Paradox®, Foxpro®, and other databases

System Requirements

- Windows® Compatible Computer
- CD-ROM Drive
- USB Port

Scale-Link works with all Windows® operating systems.



READNSTAR, INC.
PO Box 941, Carlsbad, CA 92018
1-800-991-9270 www.digitalmeasuretools.com